



*PLUS - Add a wire from the Ground Screw on the SB3 to one of the case screws of the PH Pro