



*PLUS - Add a wire from the Ground Screw on the rear of the SB3a or PH Pro box to the GND screw on the DB3