SET UP THE CAB PARAMETERS (Shortcut = PROG 5)

Press the Prog/Esc key 5 times Set Cab PARAMS, press the Enter key once.

NUMBER OF RECALLS

This adjusts the number of recall "slots" that are cycled through when the **RECALL** key is pressed. Enter a number of Recalls from 1 - 6 and press **ENTER**. This can be set differently for each Cab. (factory default is 2) Press **ENTER** to skip setting this parameter.

NUN	1BER	02:0	ØPM
OF	RECA	ALLS:	02

Press the Enter key once then press the Prog/Esc key to get out of this set up.

Put in your recalls the same as you did before, only this time you will have more "slots" to fill.

1