


PROCAB BUTTON NUMBERING SCHEME



Key #	Value	Key Name	Key #	Value	Key Name
1	67	Direction	17	96	Assign Loco -> Cab
2	94	Brake	18	98	Set Clock
3	90	Increment 4/10 steps	19	99	Use Program Track
4	47	Increment 1 Step	20	100	Set CMD Station
5	91	Decrement 4/10 steps	21	101	Set Cab Params
6	75	Decrement 1 Step	22	118	Reserved
7	123	Reserved	23	102	Setup Macros
8	81	Headlight	24	108	Select Signal
9	122	F10-F28	25	119	Reserved
10	125	"No Key" pressed	26	103	Setup Old Consist
11	116	Reserved	27	108	Select Signal
12	109	Reserved	28	120	Reserved
13	121	Reserved	29	115	Reserved
14	117	Reserved	30	112	Function 10
15	111	Momentum	31	113	Function 11
16	97	Program on Main	32	114	Function 12

Factory Shifted Keys For Ver. 1.3