Power Supply

Track Out

DCC

Auto SW

NCE
AUTO-SW

DCC

POWER

TRACK

PCAB-PP

Power Cab
Power Panel

MAIN   PROG

Main

Program
Do not use
these outputs

Power Cab

Program Track

Double Gaps

Main Track

"Live" Program Track with Auto SW